


Question : I have 12 US3000 before, which were divided into 3 groups and connecting to 1 LV-HUB. Now I just added 4 US3000C in the system. I have tried 2 connection ways:

1. I put the 4 US3000C as the fourth group but the LV-HUB cannot recognize this group.
2. I add the US3000C in the existing 3 groups and has used them as masters but the LV-HUB gives me a red alarm. How could I solve this?


Answer: Actually, US3000C has a totally different HUB cable connection method with US3000. The basic rule is still: Please use the C-version batteries as masters. So you can connect the system in this way:

1. Divide the 16 batteries to 2 groups. The first group contains 2 US3000C(one as master) and 6 US3000(slave). The 2nd group also contains 2 US3000C(one as master) and 6 US3000(slave).The cable connection for each group is the same as before. Link port 1 from previous battery should be connected to Link port 0 of the latter one. Parallel connect the power cables.




No. 73, Lane 887, Zu Chongzhi Road, Zhangjiang Hi-Tech Park
 Pudong, Shanghai 201203, China
 TEL: +86-21-51317690
 FAX: +86-21-51317698
 www.pylontech.com.cn

2. Then connect the 2 group batteries in parallel. Note that the cable connection is changed.



Attention that US3000C has different pin definitions, so the communication cable between the master battery in first group and LV-HUB should be changed. The first 3 pins of the port on battery side should be NULL!





No. 73, Lane 887, Zu Chongzhi Road, Zhangjiang Hi-Tech Park
Pudong, Shanghai 201203, China
TEL: +86-21-51317690
FAX: +86-21-51317698
www.pylontech.com.cn

3. The system switch-on process is also different. After finishing all the power cable connection, you should:

Make sure all dipswitch is 0000, then turn ON batteries.

After all batteries running and buzzer of master battery in group1 rings 3 times. Means all groups are online.

Then change the dip switch of master battery in group1 to 0100.

Then connect communication cable between LV-HUB and master battery in group 1.

Then turn ON LV-HUB.